



Package Contents

Wrist Transmitter incl. battery,
Wrist strap (latch nickel-free),
Operating instruction

Start-Up

Attach the wrist strap to the transmitter.

Transfer the transmission code to the radio control.

For this read the operating instruction supplied with the radio control.

Operating the Transmitter

Press the transmission button. The transmitter's LED lights up. The transmitter transmits as long as the button is pressed.

After max. 36 seconds, the transmission process is stopped automatically. Press the transmit button again to repeat the transmission process.

Battery Check

The transmitter has a battery check function, which checks the capacity of the battery during the transmission process.

If the battery is weak, the LED blinks during transmission.

At the end of the transmission process, an undervoltage signal is transmitted automatically. With this function, you can monitor the capacity of the battery on an additional control device.

If you want to use the additional control, you have to program the undervoltage signal into the radio control as follows:

1. Keep the transmission button pressed until the LED goes off (at least 36 seconds).

2. Keep the transmission button pressed and at the same time activate the channel of the radio control to which you want to program with the undervoltage signal. (Also see the operating instructions for the control.)

3. Release the transmission button. The LED blinks approx. 4 times to indicate that the undervoltage signal was transmitted.

If the voltage of the battery is too low, the radio control switches the connected control device.

Replacing the Battery

We recommend having the battery replaced by your retailer.

Detailed instructions for exchanging the battery are contained in the instruction manual for the Battery Exchange Set RT26-ACC-01.

Troubleshooting

- If the LED does not light up at all: exchange the battery or make sure that the polarity of the battery is correct.
- If the LED flashes permanently during the transmission procedure: exchange the battery.
- If the radio control doesn't react: move closer to the radio control or re-transmit the transmission code to the radio control.

Warranty

Within the statutory warranty period we undertake to rectify free of charge by repair or replacement any product defects arising from material or production faults.

Any unauthorized tampering with, or modifications to, the product shall render this warranty null and void.

Conformity

This product complies with the essential requirements of the R&TTE directive 1999/5/EG.



For use in: EU/CH/FL/IS/N

The Declaration of Conformity is available on the Internet at: www.eldat.de.

Disposal

Waste electrical products and batteries should not be disposed of with household waste!

Dispose of the waste product via a collection point for electronic scrap or via your specialist dealer.



Dispose of used batteries in a recycling bin for batteries or via the specialist trade.



Put the packaging material into a recycling bin for cardboard and paper.

Customer Service

If, despite correct handling, faults or malfunctions occur or if the product was damaged, please contact the company at the address below:

ELDAT GmbH
Im Gewerbepark 14
15711 Zeesen
Germany

Phone: +49(0)3375/90 37-0
Fax: +49(0)3375/90 37-90
Internet: www.eldat.de
E-mail: info@eldat.de

Models

RT26-5001E-02 868.30 MHz

Technical Data

Coding: Easywave

Modulation: FSK

Range: approx. 30 m (up to 100 m under favourable free-field conditions).

Power supply: 1 x 3 V lithium battery, CR 2032

Degree of protection: IP65

Operating temperature: -20°C to +60°C

Dimensions:

35 x 40 x 16 mm *)

Weight:

16 g *) (including battery)

*) without wrist strap

Intended Use

This Wrist Transmitter may only be used to operate Easywave radio controls.

The manufacturer shall not be liable for any damage caused by improper or non-intended use.

Safety Advice



Do not make any unauthorized alterations or modifications to the Wrist Transmitter!

Keep the Wrist Transmitter away from children!

Note also the operating instructions of the radio control!